#### **VIN Identification**



The Vehicle Identification Number (VIN) is a unique code to help identify a vehicle. It comprises of a sequence of letters and number which represent the World Make Identifier, Maruq, Model, Class, Body, Engine, Transmission, Steering, Model Change, Assembly Plant and Serial Number\*. When ordering parts or discussin your car with a dealer always quote this number.

The VIN can be found stamped on the right hand front suspension turret and on a plate which is visible in the left hand corner of the windscreen.

\* Effective from November 1998

# **SAR** RJ S T H K Y M 100321

The 1st, 2nd and 3rd letters are the World Make Identifier

# SAR RJ S T H K Y M 10032'

The 4th and 5th letters show the make and model. In this case RJ = Rover75

# SAR RJ S T H K Y M 100321

The 6th letter represents the class of vehicle, e.g.

 $\begin{array}{lll} H = & \text{Classic (TL2)} & X = & \text{MG (TL5.1)} \\ L = & \text{MG (TL7.1)} & Z = & \text{Connoisseur (TL7)} \\ \end{array}$ 

S = Comfort (TL4)

# SAR RJ S T H K Y M 100321

The 7th letter represents the body

L = Saloon T = Tourer

# SAR RJ S T H K Y M 100321

The 8th letter represents the engine type:

P = 18K4F, 1800 Petrol K = 20K4F, 2000 Petrol L = 25K4F, 2500 Petrol H = 204D2, 2000 Diesel S = 25K4F, 160PS 2500 Petrol F = 25K4F, 190PS 2500 Petrol

#### SAR RJ S T H K Y M 100321

The 9th letter represents the transmission & steering:

B = 1800P Manual RHD N = 1800P Manual LHD C = 2000D Manual RHD P = 2000D Manual LHD D = 2000P Manual RHD R = 2000P Manual LHD E = 2500P Manual RHD S = 2500P Manual LHD F = 2500P Manual RHD T = 2500P Manual LHD J = 1800P Auto RHD W = 1800P Auto LHD K = 2000D Auto RHD X = 2000D Auto LHD Y = 2000P Auto LHD L = 2000P Auto RHD M = 2500 Auto RHDZ = 2500 Auto LHD

# SAR RJ S T H K Y M 100321

The 10th letter represents the model year:

X = 1999 Model Year 2 = 2002 Model Year 5 = 2005 Model Year

Y = 2000 Model Year 3 = 2003 Model Year 1 = 2001 Model Year 4 = 2004 Model Year

# SAR RJ S T H K Y M 100321

The 11th letter denotes the assembly plant:

D = Longbridge M = Cowley

# SAR RJ S T H K Y M 100321

The final series of numbers is the serial number

This information is produced without warranty and is to be used without recourse in the event of any error directly or indirectly dishlo information within this document